

Network Camera

Quick Guide

DC-M4211WX

DC-M4211WRX

DC-M4211HRX



Safety Precautions

WARNING

RISK OF ELECTRIC SHOCK DO NOT OPEN

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO OUALIFIED SERVICE PERSONNEL.

Important Safeguards

1. Read Instructions

All the safety and operating instructions should be read before the appliance is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Cleaning

Unplug this equipment from the wall outlet before cleaning it. Do not use liquid aerosol cleaners. Use a damp soft cloth for cleaning.

4. Attachments

Never add any attachments and/or equipment without the approval of the manufacturer as such additions may result in the risk of fire, electric shock or other personal injury.

5. Water and/or Moisture

Do not use this equipment near water or in contact with water.

6. Placing and Accessories

Do not place this equipment on an wall or ceiling that is not strong enough to sustain the camera. The equipment may fall, causing serious injury to a child or adult, and serious damage to the equipment. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.



This equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

Do not place this equipment in an enclosed space. Sufficient ventilation is required to prevent an increase in ambient temperature which can cause malfunction or the risk of fire.

7. Power Sources

This equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power, please consult your equipment dealer or local power company.

You may want to install a UPS (Uninterruptible Power Supply) system for safe operation in order to prevent damage caused by an unexpected power stoppage. Any questions concerning UPS, consult your UPS retailer.

This equipment should be remain readily operable.

8. Power Cord

Operator or installer must remove power and TNT connections before handling the equipment.

9. Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the equipment due to lightning and power-line surges. If thunder or lightning is common where the equipment is installed, use a surge protection device.

10. Overloading

Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

11. Objects and Liquids

Never push objects of any kind through openings of this equipment as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the equipment.

12. Servicing

Do not attempt to service this equipment yourself. Refer all servicing to qualified service personnel.

13. Damage requiring Service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

A. When the power-supply cord or the plug has been damaged.

- B. If liquid is spilled, or objects have hit the equipment.
 C. If the equipment has been exposed to rain or water.
- D. If the equipment does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- E. If the equipment has been dropped, or the cabinet damaged.
- F. When the equipment exhibits a distinct change in performance
 this indicates a need for service.

14. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

15. Safety Check

Upon completion of any service or repairs to this equipment, ask the service technician to perform safety checks to determine that the equipment is in proper operating condition.

16. Field Installation

This installation should be made by a qualified service person and should conform to all local codes.

17. Correct Batteries

Warning: Risk of explosion if battery is replaced by an incorrect type. Replace only with the same or equivalent type. Dispose of used batteries according to the instructions. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

18. Tmra

A manufacturer's maximum recommended ambient temperature (Timra) for the equipment must be specified so that the customer and installer may determine a suitable maximum operating environment for the equipment.

FCC Compliance Statement

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION ACAINST HARMFUL INTERFERNCE WHEN THE EQUIPMENT IS OFERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO ADDIC COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELYTO CAUSE HARMFUL INTERFERENCE, IN WHICH CASE USERS WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT THEIR OWN EXPENSE.

WARMING: CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. THIS CLASS OF DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE CAUSING EQUIPMENT REGULATIONS.

WEEE (Waste Electrical & Electronic Equipment)

Correct Disposal of This Product

(Applicable in the European Union and other European countries with separate collection systems)



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Copyright

© 2025 IDIS Co., Ltd.

IDIS Co., Ltd. reserves all rights concerning this document.

 $Use \ or \ duplication \ of \ this \ document \ in \ part \ or \ whole \ without \ the \ prior \ consent \ of \ IDIS \ Co., \ Ltd. \ is \ strictly \ prohibited.$

Contents of this document are subject to change without prior notice for reasons such as functionality enhancements.

Registered Trademarks

IDIS is a registered trademark of IDIS Co., Ltd.

Other company and product names are registered trademarks of their respective owners.

The information in this manual is believed to be accurate as of the date of publication even though explanation about some functions may not be incorporated. We are not responsible for any problems resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.

The software included in this product contains some Open Sources. You may obtain the corresponding source code which we have to distribute according to the license policy. For more information, refer to **System > General** page. This product includes software developed by the University of California, Berkeley and its contributors, and software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl.org/). Also, this product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

Covered by one or more claims of the patents listed at patentlist.accessadvance.com.

Accessories

Upon purchasing the product, check inside the box to make sure all the following accessories are included. Some parts may differ depending on the situation.

ltem			
Network Camera	Bushing		
Network Camera	(DC-M4211WX, DC-M4211WRX: 3 ea., DC-M4211HRX: 4ea.)		
Allen Wrench	Camera Insulator		
Screws and Anchors (DC-M4211WX, DC-M4211WRX: 3 ea., DC-M4211HRX: 4ea.)	Desiccant for replacement and double-sided tape		
Quick Guide	Protect Guard, RJ45 Boot		

Overview




- · Product color and design may vary depending on the model.
- · For more details on each part name, refer to the manual.

Please download software (IDIS Discovery, IDIS Center, IDIS Solution Suite Compact) and product manual from this link:


- IDIS Website (www.idisglobal.com)
- Search IDIS Discovery, IDIS Center, IDIS Solution Suite Compact.

Dome Cover

DC-M4211WX/DC-M4211WRX




DC-M4211HRX




Body

DC-M4211WX




0	Lens	4	Factory Reset Button	
2	Dome Cover Assembly part	6	SD Memory Card Slot	
3	Wall/ Ceiling Installation Hole	6	Rubber Gasket	

DC-M4211WRX




0	Lens	6	IR LED
2	Ambient light sensor		Wall/ Ceiling Installation Hole
3	Built-in Microphone		Dome Cover Assembly part
4	Factory Reset Button	8	SD Memory Card Slot

DC-M4211HRX



0	Lens	6	IR LED
2	Ambient light sensor	6	Wall/ Ceiling Installation Hole
4	4 Factory Reset Button		Dome Cover Assembly part
		8	SD Memory Card Slot

I/O Device Port



0	BNC Video Out
•	Natural Port

Camera Installation


Removing the Dome Cover

DC-M4211WX/DC-M4211WRX

1 Loosen the screws counterclockwise using the allen wrench provided with the product.




2 Remove the dome cover.




DC-M4211HRX

1 Loosen the screws counterclockwise using the allen wrench provided with the product.




2 Remove the dome cover.




Inserting a SD Memory Card

Insert a SD memory card into the SD memory card slot with the 'micro SD' print facing upward.

DC-M4211WX/DC-M4211WRX




DC-M4211HRX




√

Push the SD memory card until it disengages from the slot, and then pull it out.

Waterproof Cable Installation



- Install the Protect Guard over the network cable.
- Insert the network cable into the RJ45 Boot.
- 3 Insert the cable through the RJ45 Boot.



- 4 Remove the Protect Guard and connect the camera cable.
- Push the RJ45 Boot up and turn it counterclockwise tightly.



Push up the RJ45 Boot and arrange it so that the bushing has to be out of the cable.


Installation



- Check the wall or ceiling to see if it needs to be reinforced. The camera may fall off if the wall or ceiling is not strong enough to support its weight.
- Install the camera in a shaded area. If the camera is installed in direct sunlight, it may be affected adversely.

DC-M4211WX/DC-M4211WRX


1 After you insert the SD memory card in the camera, secure the body on a wall or ceiling using the screws and anchors that came with the camera.



- 2 Connect external device and the network cable.
- Adjust the angle. For more information, refer to the **Angle Adjustment**.

DC-M4211HRX


1 After you insert the SD memory card in the camera, secure the body on a wall or ceiling using the screws and anchors provided with the camera.




- 2 Connect external devices, the network cable, and the power adapter.
- Adjust the angle. For more information, refer to the **Angle Adjustment**.

Angle Adjustment

DC-M4211WX/DC-M4211WRX



DC-M4211HRX



Closing the dome cover

Secure the top cover to the body by turning clockwise.




A powered screwdriver may be used with the lowest torque setting. (7 Kgf-cm)

DC-M4211WX/DC-M4211WRX



DC-M4211HRX



Specifications

Operating	DC-M4211WX,	 -30°C ~ 55°C (-22°F ~ 131°F)		
Temperature DC-M4211WRX		,		
	DC-M4211HRX	- 40°C ~ 60°C (-40°F ~ 140°F)		
Boot Up	DC-M4211WX,	0°C ~ 55°C (32°F ~ 131°F)		
Temperature	DC-M4211WRX	0 6 ~ 33 6 (32 F ~ 131 F)		
-	DC-M4211HRX	-20°C ~ +60°C (-4°F ~ 140°F)		
Operating Humidity		0% ~ 90%		
Power Source	DC-M4211WX	PoE (IEEE 802.3af Class 2)		
	DC-M4211WRX,	D 5 ((555 000 2 (51 - 2)		
	DC-M4211HRX	PoE (IEEE 802.3af Class 3)		
Power	DC-M4211WX	PoE (IEEE 802.3af Class 2), 6.3W		
Consumption	DC-M4211WRX	PoE (IEEE 802.3af Class 3), 8.9W		
Consumption	DC-M4211HRX	PoE (IEEE 802.3af Class 3), 9.5W (Heater on)		
Approval	DC-M4211WX,	FCC, CE, MIL-STD-810G, IP67, IK10		
	DC-M4211WRX	T CC, CE, MIE 51D 010G, II 07, IKTO		
	DC-M4211HRX	FCC, CE, MIL-STD-810G, IP69K, IK10, IK08		
External	DC-M4211WX,	104		
Dimensions (Ø x H)	DC-M4211WRX	104mm x 122.17mm x 49.44mm (4.09" x 4.8" x 1.95")		
	DC-M4211HRX	140mm x 126mm x 73.57mm (5.51" x 4.96" x 2.90")		
Weight (Main Unit) DC-M4211WX		0.37kg (0.81lbs)		
	DC-M4211WRX	0.361kg (0.79lbs)		
	DC-M4211HRX	0.66kg(1.46lbs)(PC)		
		0.67kg(1.48lbs)(TG)		
Edge storage* (Optional)		Micro (micro SD/SDHC/SDXC memory card (class 6 or higher, max.		
		512GB))		

^{*} An SLC (Single Level Cell) or MLC (Multi Level Cell) card by SanDisk or Transcend is recommended to ensure stable recording performance.

- DirectIP NVR makes it easy to use cameras without extra network configurations.
 Each camera can be controlled via the DirectIP® NVR setup menu, without any PC.
 - For detailed camera settings, please see the camera setting pages of DirectIP® NVR manual.
- To use your camera with non-DirectIP system (e.g. other NVR or VMS), refer to the camera manual and it can be downloaded from our website: <u>www.idisqlobal.com</u>.

^{*} An SD memory card is a consumable product with a finite service life. Prolonged use will damage the card's memory sectors and result in data loss or memory card failure. Test the SD memory card regularly and replace it whenever necessary.

^{*} microSD Logo is a trademark of SD-3C, LLC.



IDIS Co., Ltd.

For more information, please visit www.idisglobal.com